

Wireless Keyboard Information Sheet

The LifeShare service can also be used with a wireless keyboard instead of a remote, this is ideal for users who frequently send messages through LifeShare. To buy a wireless keyboard for \$40, contact us at (317)-825-0320; although any wireless keyboard works as long as it is USB compatible.

Contents

- Wireless Keyboard
- USB Receiver
- 2 AAA Batteries

Connecting the Keyboard to the Set-top Box

- Insert the batteries into the keyboard.
- Plug in the USB Receiver into the USB port on the box.

Operating LifeShare with the Keyboard

General Navigation

The Up, Down, Left, and Right arrow keys on the keyboard are used to move throughout LifeShare system.

Home Button

The "Esc" key on the keyboard will always return you to the home page. This is used to reorient you and quickly get back to the main menu.

Sending a Response or New Message

Once you have completed typing your message, hit the "Tab" key to get to the Edit / Send / Cancel options. Then use the Left and Right arrow keys to highlight "Edit," "Send," or "Cancel." Hit the "Return" (or Enter) key to choose the option you have highlighted.

- The "Edit" option allows you to return to the typing area to adjust the message.
- The "Send" option is used to send the message.
- The "Cancel" option will exit your message without sending it.

Select or OK

The "Return" (or Enter) key on the keyboard is equivalent to "Ok."