






Programming the LifeShare Remote

Note: You cannot program the black buttons on the LifeShare remote.

To program the Lifeshare remote:

1. Press and hold the  button until the red light stays lit (about 5 seconds).
2. Point the sensors at the tip of the remotes at each other.
3. Press the button to be programmed on the LifeShare remote. The red light will flash.
4. Press the desired button on the TV remote. The red light will flash twice then stay lit.
5. Repeat steps 3 and 4 on the other buttons you wish to program. When finished, press and hold  button until the red light turns off.
6. If the red light turns off, you will need to restart at step 1.

To remove custom remote programming, hold down the  button and the  button until the red light blinks 3 times (about 5 seconds).



LifeShare Home

Power

Return to T.V.

The **red power button** and all of the **blue buttons** below the arrow keys can be programmed to your TV remote.